


Springboard®



1 Pneumatic seat height

To raise chair, lift body weight up and pull lever up. To lower chair, remain seated and pull lever up.

2 Tilt tension

To decrease tension, turn counterclockwise. To increase tension, turn clockwise.

3 Upright back lock

To release, lean forward and pull toward back. To lock, lean forward and push toward front.

4 Lumbar height

Lean forward, turn wheels up to lower, and turn wheels down to raise.

5 Adjustable seat depth

Pull lever up and hold, shift seat forward or back, and release lever to lock.

6 Seat angle

Pull lever back and hold, shift seat to desired angle, and release lever to lock.

7 Arm height

Pull trigger up and hold, pull arm up or push down, and release trigger to lock.

8 Arm width

Grasp arm caps, flip over.

note: your chair may not have all the adjustments shown.

Springboard[™]
turnstone[®]

www.turnstonefurniture.com

turnstone
A Steelcase Company